Add a Network Interface without using USB

The Pi Zero has the limitation of only having a single USB port. If you want to put your Pi Zero on the LAN, then you need to add a network port, this is normally done using a USB Nic.

I hate buying anything for the Pi Zero that costs proportionally more than the Pi Zero, and USB network adapters fall in to that category. Pay a few quid for one, and you only get a crappy unreliable Nic that is sold as USB2, but is normally an old USB 1.x and that fails all the time, believe me, I have tried a lot of them.

Then I came across this website http://raspi.tv/2015/ethernet-on-pi-zero-how-to-put-an-ethernet-port-on-your-pi

What they have done is used a network module that runs on the SPI bus. Its a cheap unit that you can get from ebay for around £3, and while they are cheap, they are reliable, albeit a little slow, but not so slow that they are unusable. I will take reliability over speed any day.

Here is the unit I purchased from eBay for £2.07p



The seller on eBay is chips-fans and while it has the same part number as the one used on raspi.tv, the pins are different, which is a bit annoying, but it wasn't to hard to work out.

Connecting the NIC

Here are the connections I used for this board:

GPI0 n/c n/c GPI010 GPI008 3v3 GPI025	RPi Pin 19 24 17 22	Nic PNo 1 2 3 4 5	Nic Func CLK WOL SI CS Vcc NT
GPI008	24	4	
3v3	17	5	Vcc
GPI025	22	6	NT
GPI009	21	7	S0
GPI011	23	8	SCK
n/c		9	RST
GND	20	10	GND

Configuration

Enable the SPI Pins:

From the command line

 $\frac{\text{update:}}{2023/03/09} \ \text{add_a_network_interface_without_using_usb\ http://cameraangle.co.uk/doku.php?id=add_a_network_interface_without_using_usb\&rev=1472334510}$

sudo raspi-config Advanced Options - SPI - Yes to Enable

http://cameraangle.co.uk/ - WalkerWiki - wiki.alanwalker.uk

Permanent link:

http://cameraangle.co.uk/doku.php?id=add_a_network_interface_without_using_usb&rev=1472334510

Last update: 2023/03/09 22:35



Printed on 2024/05/14 19:50 http://cameraangle.co.uk/