

Console Commands

Note: At the time of writing (Oct2016) any upgrade to the MFEL will wipe any custom Console commands

When configuring the MFEL (Muse Live) there are some options that can not be set from the web interface, for these extra settings we can use the Console.

Enter the following address in to the web browser

```
http://<ip address>/Console
```

To login, use the following credentials:

```
admin  
envivio
```

There are many commands that can be entered here, I will list them as I discover them.

- [Default v7 Console Parameter List](#)
- [Fix for vertical resolution when using progressive outputs](#)
- [Force CBR mode by adding null packets](#)
- [Force 1080i25 to 1080p50 in Stat Mux](#)
- [Proximus changes](#)
- [mpeg2ts.slave](#)
- [Interlacing Fix](#)
- [Example Command List](#)
- [De-Interlace in IPTV](#)
- [IDR Management](#)
- [Set PES packet length to 0](#)
- [For the value of em_data](#)
- [Image Loss Choice](#)
- [Confirmation message on stop encoding](#)
- [Regionalised Statmux](#)
- [Change DVB Subs Language](#)
- [Different timeout for source switch](#)
- [Blackout Redundancy](#)
- [Output virtual IP duplication check](#)
- [Remove Cross Conversion Alarm](#)
- [Disable Reference B Frames in HEVC](#)

Console Settings File Location

What the console opens is a text configuration file on the muse. You can view and edit this file without using the console by browsing to the following location on the MFEL (Muse).

```
/opt/envivio/muse/ini/mpeg4.cfg
```

From:
<http://cameraangle.co.uk/> - WalkerWiki - wiki.alanwalker.uk

Permanent link:
http://cameraangle.co.uk/doku.php?id=wiki:console_commands

Last update: 2023/03/09 22:35



