

Basic Intervalometer

Jun 2017

So here is a command line to use `gphoto2` as a basic intervalometer. You can type this in at the terminal, or you could use a python script to generate this command line based on user input.

```
gphoto2 --interval=10 --frames=10 --capture-image-and-download
```

So in this example, we are going to capture 10 frames, at an interval of 10 seconds, and download each file.

```
Time-lapse mode enabled (interval: 10s).
Capturing frame #1/10...
Waiting for next capture slot 9 seconds...
New file is in location /store_00020001/DCIM/100CANON/IMG_5934.CR2 on the camera
Downloading 'IMG_5934.CR2' from folder '/store_00020001/DCIM/100CANON'...
Saving file as IMG_5934.CR2
Deleting file /store_00020001/DCIM/100CANON/IMG_5934.CR2 on the camera
Deleting 'IMG_5934.CR2' from folder '/store_00020001/DCIM/100CANON'...
Capturing frame #2/10...
Waiting for next capture slot 9 seconds...
New file is in location /store_00020001/DCIM/100CANON/IMG_5935.CR2 on the camera
Downloading 'IMG_5935.CR2' from folder '/store_00020001/DCIM/100CANON'...
Saving file as IMG_5935.CR2
Deleting file /store_00020001/DCIM/100CANON/IMG_5935.CR2 on the camera
Deleting 'IMG_5935.CR2' from folder '/store_00020001/DCIM/100CANON'...
Capturing frame #3/10...
Waiting for next capture slot 9 seconds...
New file is in location /store_00020001/DCIM/100CANON/IMG_5936.CR2 on the camera
Downloading 'IMG_5936.CR2' from folder '/store_00020001/DCIM/100CANON'...
Saving file as IMG_5936.CR2
Deleting file /store_00020001/DCIM/100CANON/IMG_5936.CR2 on the camera
Deleting 'IMG_5936.CR2' from folder '/store_00020001/DCIM/100CANON'...
etc..
```

It can be seen that after the image is downloaded, it is deleted also. If you don't want the files deleted, use the following syntax.

```
gphoto2 --interval=10 --frames=10 --capture-image-and-download --keep
```

Here are the 10 files I captured

```
IMG_5934.CR2  IMG_5936.CR2  IMG_5938.CR2  IMG_5940.CR2  IMG_5942.CR2
IMG_5935.CR2  IMG_5937.CR2  IMG_5939.CR2  IMG_5941.CR2  IMG_5943.CR2
```

WARNING!!! If you pick a short interval (say 3 or 4 seconds) then the Raspberry Pi may not be able to write the files fast enough, and you may end up with dropped frames (if you use the `-keep` switch, they will still be on the camera memory card though).

If you need a relatively short interval, then just use the following syntax to capture the files, then download them at the end of the capture.

```
gphoto2 --interval=3 --frames=10 --capture-image
```

Here you can see the files are captured, but not copied or deleted (you don't have to use the `-keep` switch if you are not downloading at the same time).

```
Time-lapse mode enabled (interval: 3s).
Capturing frame #1/10...
Waiting for next capture slot 2 seconds...
New file is in location /store_00020001/DCIM/100CANON/IMG_5964.CR2 on the camera
Capturing frame #2/10...
Waiting for next capture slot 2 seconds...
```

New file is in location /store_00020001/DCIM/100CANON/IMG_5965.CR2 on the camera
Capturing frame #3/10...
Waiting for next capture slot 2 seconds...
New file is in location /store_00020001/DCIM/100CANON/IMG_5966.CR2 on the camera

From:

<http://cameraangle.co.uk/> - WalkerWiki - wiki.alanwalker.uk

Permanent link:

http://cameraangle.co.uk/doku.php?id=basic_intervalometer

Last update: **2023/03/09 22:35**

